

OUTLE - 01-5138 - ARQ.JAGUAR 14V

DAIMLER DAIMLER SIX 4.0 1994 - 2003 3980CC, 6CYL, 241HP DAIMLER XJ DOUBLE SIX 6.0 1993 - 1994 5993CC, 12CYL, 311HP DAIMLER XJ SOVEREIGN 3.6 1986 - 1989 3590CC, 6CYL, 185HP DAIMLER XJ SOVEREIGN 3.6 1986 - 1989 3590CC, 6CYL, 197HP DAIMLER XJ SOVEREIGN 4.0 1989 - 1994 3980CC, 6CYL, 222HP JAGUAR XJ 3.6 1983 - 1987 3590CC, 6CYL, 228HP JAGUAR XJ 3.6 1983 - 1988 3590CC, 6CYL, 220HP JAGUAR XJ 3.6 1987 - 1989 3590CC, 6CYL, 212HP JAGUAR XJ 3.6 1988 - 1991 3590CC, 6CYL, 199HP JAGUAR XJ 3.6 1988 - 1992 3590CC, 6CYL, 185HP JAGUAR XJ 3.6 24V 1983 - 1987 3590CC, 6CYL, 212HP JAGUAR XJ 3.6 XJS 1983 - 1987 3590CC, 6CYL, 212HP JAGUAR XJ 3.6 XJS 1983 - 1987 3590CC, 6CYL, 228HP JAGUAR XJ 3.6 XJS 1983 - 1988 3590CC, 6CYL, 220HP JAGUAR XJ 3.6 XJS 1987 - 1989 3590CC, 6CYL, 212HP JAGUAR XJ 3.6 XJS 1988 - 1991 3590CC, 6CYL, 199HP JAGUAR XJ 3.6 XJS 1988 - 1992 3590CC, 6CYL, 185HP JAGUAR XJ 4.0 1991 - 1994 3980CC, 6CYL, 222HP JAGUAR XJ 4.0 1994 - 1996 3980CC, 6CYL, 233HP JAGUAR XJ 4.0 XJS 1991 - 1994 3980CC, 6CYL, 222HP JAGUAR XJ 4.0 XJS 1994 - 1996 3980CC, 6CYL, 233HP JAGUAR XJ 6 2.9 1986 - 1990 2919CC, 6CYL, 147HP JAGUAR XJ 6 2.9 1986 - 1990 2919CC, 6CYL, 159HP JAGUAR XJ 6 2.9 1986 - 1990 2919CC, 6CYL, 167HP JAGUAR XJ 6 3.2 24V 1990 - 1994 3239CC, 6CYL, 199HP JAGUAR XJ 6 3.6 1986 - 1989 3590CC, 6CYL, 185HP JAGUAR XJ 6 3.6 1986 - 1989 3590CC, 6CYL, 197HP JAGUAR XJ 6 3.6 1986 - 1989 3590CC, 6CYL, 212HP JAGUAR XJ 6 4.0 1989 - 1994 3980CC, 6CYL, 222HP JAGUAR XJ V12 6.0 1993 - 1994 5993CC, 12CYL, 311HP

BOSCH 0001110011 BOSCH 0986015740 BOSCH 1574 LUCAS 25755 LUCAS 27756 LUCAS LRS00525 LUCAS LRS525 LUCAS LRT00160 LUCAS LRT160